


Lamello Invis Mx2

Clamps – Invisible – Detachable



The unique magnet-driven connection with an even higher clamping force!





60% higher clamping force250 kg clamping force per connector

Even more applications

The MiniMag Mx2 drive opens or closes the connection:

Hammering sound = clamps Rolling sound = open

The speed of the cordless drill must be 1200 - 1500 rpm




- Powerfully joined workpieces
- Detachable in seconds
- Completely invisble

No openings | No protective caps | No filler | A perfect look!



Clamps

- 1. Clamp molded high-gloss painted parts or furniture without damage
- 2. Transport large living room furniture in pre-assembled parts and join them quickly on site
- 3. Install stair treads without glue waiting time
- 4. Prepare hand rails in the workshop and glue them on site without clamps















Invisible

5. Join and plaster substructures without needing to fill holes

- 6. Join separating walls without visible fixings
- 7. Transport furniture in parts and still assemble them invisibly
- 8. Open shelves with perfect aesthetics without visible fasteners
- 9. Install detachable wall panels quickly and invisibly











Detachable

- 10. System furniture with option to add-on more elements
- 11. Disassemble large furniture to move
- 12. Quickly assemble and dismantle exhibition furniture
- 13. Join table legs without visible fasteners and unscrew them again if necessary









Videos System video





Hand rail





Stairs





Simple cabinet





Dividing panel






Table leg





Drill

Drill with CNC, stationary machine or drill jig



CNC | Rasto

Small distance for high clamping force


Ø12×37 mm

9 – max. 20 mm

Ø12×

14 mm

9 mm – max. 20 mm









Rasto Drill jig

- Precise drilling
- No measuring or marking
- For any workpiece shape





Furniture handle holes and 32 mm hole rows

- Use positioning pins as stops instead of measuring the hole position
- Insert the pins into the jig and drill the first workpiece
- Screw the drill bush into the opposite face of the jig
- Drill the second workpiece with the same pin position
- Transparency for perfect alignment to a pencil mark
- 180 positioning holes for many applications in many shapes and sizes



